

BASAMENTI TIFFANY

Design Centro Stile Scab

Staffe di fissaggio al piano in fusione di ghisa.
Da assemblare.
Cast iron spider. Disassembled.

TIFFANY

Base quadrata. Colonna quadrata 50x50 mm.
Square base. 50x50 mm square column.



FINITURA BASE E COLONNA
BASE AND COLUMN FINISHES



ART. 5183

ART. 5182

ART. 5188



solo per / only for ART. 5182, ART. 5188


TIFFANY

Base quadrata. Colonna quadrata 80x80 mm.
Square base. 80x80 mm square column.

FINITURA BASE E COLONNA
BASE AND COLUMN FINISHES



ART. 5180




BASE
BASE




TIFFANY

Base quadrata. Colonna quadrata 80x80 mm.
Square base. 80x80 mm square column.


FINITURA BASE E COLONNA
BASE AND COLUMN FINISHES



ART. 5187



ART. 5185



solo per / only for ART. 5185

Алматы (7273)495-231
Ангарт (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47


<https://scab.nt-rt.ru/> || sbj@nt-rt.ru

NATURAL TIFFANY



Base quadrata. Colonna quadrata 80x80 mm in legno massello.
Square base. 80x80 mm square solid wood column.

ART. 5150



FINITURA BASE
BASE FINISHES



IS IL

FINITURA COLONNA
COLUMN FINISHES




FN FW

TIFFANY




Base quadrata. Colonna tonda da Ø 76 mm
Square base. 76 mm diam. round column.

ART. 5181



ART. 5186



FINITURA BASE E COLONNA
BASE AND COLUMN FINISHES




IS IL

TIFFANY




Base rettangolare. Colonna quadrata 80x80 mm.
Rectangular base. 80x80 mm square column.

ART. 5080



ART. 5085



FINITURA BASE E COLONNA
BASE AND COLUMN FINISHES



IS VN FX



IL VN


solo per / only for ART. 5080

NATURAL TIFFANY



Base rettangolare. Colonna quadrata 80x80 mm in legno massello.
Rectangular base. 80x80 mm square solid wood column.

ART. 5050



FINITURA BASE
BASE FINISHES



IS IL

FINITURA COLONNA
COLUMN FINISHES



FN FW


TIFFANY

Base rettangolare. Doppia colonna quadrata 80x80 mm.
Rectangular base. 80x80 mm square double column.



FINITURA BASE E COLONNA
BASE AND COLUMN FINISHES



ART. 5082




ART. 5083



TIFFANY

Base tonda. Colonna tonda da Ø 76 mm
Round base. 76 mm diam. round column.





FINITURA BASE E COLONNA
BASE AND COLUMN FINISHES



ART. 5177

ART. 5170

ART. 5175



solo per / only for ART. 5170, ART. 5175


TIFFANY XL

Base tonda XL. Colonna tonda da Ø 76 mm
XL round base. 76 mm diam. round column.

FINITURA BASE E COLONNA
BASE AND COLUMN FINISHES



ART. 5172



Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Россия +7(495)268-04-70

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://scab.nt-rt.ru/> || sbj@nt-rt.ru